

## **IMPORTANT NOTE**

**Please ensure that your spindle is cut to the correct length.  
For the optimum length add 30mm to the thickness of your door  
(e g.: door thickness 40mm + 30mm = 70mm).**

**We also recommend that you use a medium to heavy sprung  
Mortise latch with this product, for best results.**