

THE IRONMONGER

AND

METAL TRADES ADVERTISER

Registered as a Newspaper]

(PUBLISHED WEEKLY.)

[for Home and Foreign Transmission.

No. 555, Vol. XXXII.]

JULY 5, 1884.

SUBSCRIPTION (including the Diary and Text-Book),
Home, 10s.; Foreign, 20s. PER ANNUM, POST FREE.
Single Copies of "THE IRONMONGER," 6d. each.
Do. of "The Diary," 3s. post free.

14

THE IRONMONGER

inodorous, and compact means of heating halls, rooms, small conservatories, &c., at a minimum cost.

SANITARY FITTINGS.

The Sanitary Paper Company show sample rolls of toilet-paper and patterns of bronzed holders for the same. The paper rolls are prepared in lengths of 500 feet each, and, instead of being perforated at set distances, the means of removing pieces as required is provided in a cutter which is formed by the front edge of the projecting top of the holder.

Waller & Co. exhibit a closet and two urinals fitted with their patent fitted to water back of the closet below the sea

their s
ironwo
hollow
water a
ironwo
does no
claimed
poses.
applicat
is said
wise un
just as

ance, as
at the
rove and
Incline.

Mr.
new sh
contriv
an up



SANITARY PAPER COMPANY

TOILET ROLL HOLDER (1884 DESIGN)

PARTS LIST

- Toilet roll holder - Seasoned oak back plate - Wall plugs (2) & screws (6)

TOOLS REQUIRED

- Drill - 8mm masonry drill bit - Screwdriver

BEFORE YOU START

- The screws and wall plugs supplied are **only suitable for use in solid walls**. If fitting to other types of wall please source suitable fixings from your local hardware store.
- Ensure there are no hidden service pipes or cables where you intend to drill.
- If drilling into ceramic tiles you will need a special drill bit for ceramic tiles.
- Where possible, drill your holes between ceramic tiles (i.e. in the grouting).

FITTING INSTRUCTIONS

- **Step 1.** Unscrew the two small screws securing the toilet roll holder to the oak back plate. Place them safely with the other fixings, for future use.
- **Step 2.** Offer the back plate up to the wall. Ensure that it is level and then mark the wall through the two large pre-drilled holes.
- **Step 3.** Drill your two 8mm holes to a depth 2mm deeper than the length of the wall plugs provided. Tap a wall plug into each of the holes.
- **Step 4.** Secure the oak back plate to the wall using the two large fixing screws.
- **Step 5.** Secure the toilet roll holder to the back plate by screwing the four small screws into the pre-drilled holes. Ensure that these are screwed tightly into the wood.
- **Step 6.** Remove the spring loaded wooden spindle. Place the spindle through the toilet roll, ensuring that the paper feeds up and over the top. Lift the lid of the holder. Locate the end of the spindle in the hole in the holder arm and spring into position.

CLEANING

Spray with polish and wipe gently with a soft cloth.